

ACCESSORIES AND SPARE PARTS

Kitchen ceramics																
Product	Item numbers	Drain fitting		Putty	Sieve basket valve			Sieve basket			Operating element	Bowden control	Spillway	Spillway pipe	Spillway extension	Miscellaneous
		manual waste	automatic waste		manual waste	automatic waste		small	manual waste	automatic waste						
Bela 57, 57F	5016, 5516	00791	00891	50001	00873	00874			00777	00776	00798	00778	50004	50003	50006	
Bela 78, 78F	5018/5019, 5518/5519	00791	00891	50001	00873	00874			00777	00776	00798	00778	50004	50003	50006	
Bela 100, 100 F	5020/5021, 5520/5521	00791	00891	50001	00873	00874			00777	00776	00798	00778	50004	50003	50006	
Cea 57, 57F, 57U, 57U/g	5049, 5349, 5449, 5549	00749	00849	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Centra 60	5093-5094		00835	50001	00770	00773				00775	00797	00781	50009			
Centra 90	5095-5096		00853	50001	00770	00773			00774	00775	00797	00781	50009			
Delta 86	5017	00750	00850	50001	00770	00773			00774	00775	00797	00781				
Delta 90	5071	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Delta 100, 100F	5072, 5572	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Genea 75, 75F	5090, 5590	00762	00863	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Genea 87, 87F	5091, 5591	00719	00819	50001	00873	00874			00777	00776	00798	00778	50004	50003	50006	
Genea 100, 100F	5092, 5592	00748	00848	50001	00770	00773		50012	00774	00775	00797	00781	50011			
Genea Double	5030	00790	00890	50001	00770	00773			00774	00775	00797	00781				
Mera 16U, 16U/g, 24, 24F, 24F/o	5046, 5146, 5346, 5446, 5546			50001	50005											
Mera 32U, 32U/g, 39, 39F, 39F/o	5061, 5161, 5361, 5461, 5561	00762	00863	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Mera 40U, 40U/g, 46, 46F, 46F/o	5056, 5156, 5356, 5456, 5556	00749	00849	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Mera 42U, 42U/g, 51, 51F, 51F/o	5001, 5101, 5301, 5401, 5501	00749	00849	50001	00873	00847			00777	00776	00798	00778	0622	50002	50006	
Mera 50U, 50U/g, 57, 57F, 57F/o	5057, 5157, 5357, 5457, 5557	00749	00849	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Mera 60, 60F, 60F/o, 60U, 60U/g	5098, 5198, 5398, 5498, 5598	00724	00825	50001	00770	00773		00772	00774	00775	00797	00781	0621	50010		50011
Mera 70, 70F	5058/5059, 5558/5559	00762	00863	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Mera 80, 80F, 80F/o, 80U, 80U/g	5070, 5170, 5370, 5470, 5570	00747	00847	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Mera 90, 90F	5074/5075, 5574/5575	00762	00863	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Mera 100, 100F	5076/5077, 5576/5577	00724	00825	50001	00770	00773		00772	00774	00775	00797	00781	0621	50010		50011
Mera 100SL, 100SL F	5064/5065, 5564/5565	00747	00847	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Mera Double	5078/5079	00722	00822	50001	00770	00773			00774	00775	00797	00781	0621	50010		
Mera Eck, Eck F	5051, 5551	00708	00808	50001	00873	00874			00777	00776	00798	00778	50007		50006	
Mera Middle, Middle F	5073, 5573	00749	00849	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Mera Twin, Twin F, Twin F/o, Twin U, Twin U/g	5062, 5162, 5362, 5462, 5562	00758	00858	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Siro 90	5069	00762	00863	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Siro 100	5080	00747	00847	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Stema 80, 80F	5054/5055, 5554/5555	00749	00849	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Stema 86 SL, 86 SL F	5010/5011, 5510/5511	00747	00847	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Stema 90, 90F	5052/5053, 5552/5553	00709	00809	50001	00873	00874			00777	00776	00798	00778	50005		50006	
Vega 78, 78F	5038/5039, 5538/5539	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Vega Eck	5034	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Vega Eck Plus	5037	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			

ACCESSORIES AND SPARE PARTS

Kitchen ceramics

Old models (Please specify the Item No./Designation and the delivery year of the sink.)

Product	Item numbers	Drain fitting		Putty	Sieve basket valve			Sieve basket			Operating element	Bowden control	Spillway	Spillway pipe	Spillway extension	Miscellaneous
		manual waste	automatic waste		manual waste	automatic waste		small	manual waste	automatic waste						
Alpha E90	5014	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Alpha 45	5015	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Alpha 75	5010	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Alpha 95	5012	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Alpha Ergo	5025		00835	50001	00770	00773				00775	00797	00781	50009			
Alpha Ergo Plus	5090		00835	50001	00770	00773				00775	00797	00781	50009			
Beta 100	5063	00724	00825	50001	00770	00773		00772	00774	00775	00797	00781	0621	50010		50011
Cea 100	5048	00748	00848	50001	00770	00773		50012	00774	00775	00797	00781	50011			
Kappa 86	5023	00721	00821	50001	00873	00874			00777	00776	00798	00778	00793			
KSV 100	5062	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Prisma	5060	00734	00739	50001	00770	00773					00797	00781				
Quanto 60	5005-5009	00749	00849	50001	00873	00874			00777	00776	00798	00778	0622	50002	50006	
Quanto 90	5024 5026-5029	00758	00858	50001	00873	00874			00777	00776	00798	00778	0622	50002		
Sigma 52	5068	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Sigma 92	5066	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Sinus 87, 87F	5086, 5586	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Sinus 95	5088	00728	00829	50001	00770	00773			00774	00775	00797	00781				
Sinus Double	5081	00726	00827	50001	00770	00773		50012	00774	00775	00797	00781				
Sinus Eck, Eck F	5082, 5582	00728	00829	50001	00770	00773			00774	00775	00797	00781				
Vega 46, 46F	5031, 5531	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Vega 100	5032/5033	00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			
Zeta 32F, 32U		00721	00821	50001	00873	00874			00777	00776	00798	00778	00793	50002		
Zeta 40F, 40U		00721	00821	50001	00873	00874			00777	00776	00798	00778	00793	50002		
Zeta 50F, 50U		00721	00821	50001	00873	00874			00777	00776	00798	00778	00793	50002		
Zeta 52F, 52U		00730	00835	50001	00770	00773			00774	00775	00797	00781	50009			

Bathroom ceramics









Sanara 50	3522	0070034__														
Patera 40, Lavara 60	3520, 3521	0070035__														
Patera 40 U/g, Lavara 60 U/g	3420, 3421	0070034__														

ACCESSORIES AND SPARE PARTS

Spare parts	Article No.
<i>(Please specify the Item No./Designation and the delivery year of the sink.)</i>	
	Alba-sieve basket valve with manual operation Ø 115 mm Consisting of multiple parts (00792 & 00777): Bela 57, Bela 78, Bela 100, Cea 57, Genea 75, Genea 87, Kappa 86, Mera Eck, Mera 39, Mera 70, Mera 90, Mera 46, Mera 51, Mera 57, Mera Middle, Mera Twin, Quanto 60, Mera 100 SL, Siro 100, Mera 80, Quanto 90, Siro 90, Stema 80, Stema 86 SL, Stema 90, (Zeta 32, Zeta 40, Zeta 50)
	TG-sieve basket valve with manual operation Ø 115 mm (Beta 100), Cea 100, Centra 90, Delta 86, Delta 90, Delta 100, Genea 100, Genea Double, Mera 60, Mera 100 Mera Double, Sigma 52, (Sigma 92), Sinus 87, Sinus Eck, Sinus Double, (Vega 46, Vega 78), Vega 100, Vega Eck, Vega Eck Plus, (Zeta 52), plus F- and U-variants
	Sieve basket valve small bowl TG Ø 70 mm Mera 60, Mera 100, Genea 100, Cea 100, Beta 100
	Alba-sieve basket valve with automatic operation Ø 115 mm Consisting of multiple parts (00792, 00776 & 00778): Bela 57, Bela 78, Bela 100, Cea 57, Genea 75, Genea 87, Kappa 86, Mera Eck, Mera 39, Mera 70, Mera 90, Mera 46, Mera 51, Mera 57, Mera Middle, Mera Twin, Quanto 60, Mera 100 SL, Siro 100, Mera 80, Quanto 90, Siro 90, Stema 86 SL, Stema 80, Stema 90, (Zeta 32, Zeta 40, Zeta 50)
	TG-sieve basket valve with automatic operation Ø 115 mm (Alpha Ergo, Beta 100), Cea 100, Centra 60, Centra 90, Delta 86, Delta 90, Delta 100, Genea 100, Genea Double, Mera 60, Mera 100, Mera Double, Sigma 52, (Sigma 92), Sinus 87, Sinus Eck, Sinus Double, (Vega 46, Vega 78), Vega 100, Vega Eck, Vega Eck Plus, (Zeta 52), F- and U-variants
	Spillway draining board Alba Stema 90, Mera 16, Mera 24
	Spillway small bowl TG Vega, Centra, Delta 90, Delta 100
	Spillway TG square Beta 100, Mera 60, Mera 100, Mera Double
	Spillway Alba square all Meras except Mera 60, Mera 100, Mera Double, Mera Eck Stema 80, Cea 57, Stema 86, Stema 86 SL, Quanto, Siro 90, Siro 100
	Spillway Alba round Kappa 86, Zeta
	Spillway small bowl Alba square Bela, Genea 87

Spare parts	Article No.
<i>(Please specify the Item No./Designation and the delivery year of the sink.)</i>	
	Spillway articulated pipe Alba Cea 57, all Meras except Mera 60, Mera 100, Mera Double, Quanto, Siro 90, Stema 80, Stema 86 SL, Zeta
	Spillway articulated pipe TG Beta 100, Mera 60, Mera 100, Mera Double
	Spillway articulated pipe Alba Bela, Genea 87
	Spillway extension Alba Cea 57, all Meras except Mera 60, Mera 100, Mera Double, Quanto, Siro 90, Siro 100, Stema 80, Stema 86 SL, Zeta
	TG-sieve basket Ø 55 mm / for small bowl with manual operation (Beta 100), Mera 60, Mera 100
	TG-sieve basket Ø 55 mm / for small bowl functioning as spillway and not sealable Sinus Double
	Alba-sieve basket Ø 80 mm / standard for drain set with manual operation Bela 57, Bela 78, Bela 100, Cea 57, Genea 75, Genea 87, Kappa 86, Mera Eck, Mera 39, Mera 51, Mera 70, Mera 90, Mera 46, Mera 57, Mera Middle, Mera Twin, Quanto 60, Mera 100 SL, Siro 100, Mera 80, Quanto 90, Siro 90, Stema 80, Stema 86 SL, Stema 90, (Zeta 32, Zeta 40, Zeta 50)
	TG-sieve basket Ø 80 mm / standard for drain set with manual operation (Beta 100), Cea 100, Centra 90, Delta 86, Delta 90, Delta 100, Genea 100, Genea Double, Mera 60, Mera 100, Mera Double, Sigma 52, (Sigma 92), Sinus 87, Sinus Eck, Sinus Double, (Vega 46, Vega 78), Vega 100, Vega Eck, Vega Eck Plus, (Zeta 52), F- and U-variants
	Alba-sieve basket Ø 80 mm / standard for drain set with automatic operation Bela 57, Bela 78, Bela 100, Cea 57, Genea 75, Genea 87, Kappa 86, Mera Eck, Mera 39, Mera 51, Mera 70, Mera 90, Mera 46, Mera 57, Mera Middle, Mera Twin, Quanto 60, Mera 100 SL, Siro 100, Mera 80, Quanto 90, Siro 90, Stema 80, Stema 86 SL, Stema 90, (Zeta 32, Zeta 40, Zeta 50)
	TG-sieve basket Ø 80 mm / standard for drain set with automatic operation (Alpha Ergo, Beta 100), Cea 100, Centra 60, Centra 90, Delta 86, Delta 90, Delta 100, Genea 100, Genea Double, Mera 60, Mera 100, Mera Double, Sigma 52, (Sigma 92), Sinus 87, Sinus Eck, Sinus Double, (Vega 46, Vega 78), Vega 100, Vega Eck, Vega Eck Plus, (Zeta 52), F- and U-variants
	Sieve basket incl. Alba cover Mera Eck

ACCESSORIES AND SPARE PARTS

Spare parts		Article No.
<i>(Please specify the Item No./Designation and the delivery year of the sink.)</i>		
	Alba-Bowden cable Bela 57, Bela 78, Bela 100, Cea 57, Genea 75, Genea 87, Kappa 86, Mera Eck, Mera 39, Mera 70, Mera 90, Mera 46, Mera 51, Mera 57, Mera Middle, Mera Twin, Quanto 60, Mera 100 SL, Siro 100, Mera 80, Quanto 90, Siro 90, Stema 80, Stema 86 SL, Stema 90, (Zeta 32, Zeta 40, Zeta 50)	00778
	TG-Bowden cable (Alpha Ergo, Beta 100), Cea 100, Centra 60, Centra 90, Delta 86, Delta 90, Delta 100, Genea 100, Genea Double, Mera 60, Mera 100, Mera Double, Sigma 52, (Sigma 92), Sinus 87, Sinus Eck, Sinus Double, (Vega 46, Vega 78), Vega 100, Vega Eck, Vega Eck Plus, (Zeta 52), F- and U-variants	00781
	Control element for automatic operation Please quote sink model on order.	00797 00798
	Twist grip stainless steel polished round Ø 45 mm	00786
	Twist grip stainless steel satin round Ø 45 mm	00795
	Sealing Putty	50001
	Spacer sleeve for fitting attachment in the case of space problems	40001
	Blind plug	00810